

COLOURpyne

RESTRICTIONS ON USE

COLOURpyne should not be used in areas where it will be exposed to high moisture levels, for example, as wall linings for exteriors, for wet areas in regular contact with water, or for bench tops in kitchens and bathrooms.

E0 CREDENTIALS

All COLOURpyne colours are available on lower formaldehyde emission level E0 substrate to contribute to superior air quality and a healthier working environment. All COLOURpyne MDF substrate is E0. Speak to your COLOURpyne representative for more information on the benefits of using COLOURpyne E0.

CHAIN OF CUSTODY

Australian Panel Products uses PEFC Chain of Custody (C of C) certification to ensure that the vast majority of wood in COLOURpyne products is legally sourced from sustainably managed forests.

SUSTAINABILITY

Australian Panel Products is committed to an eco-friendly and sustainable environment. It is an intrinsic part of our manufacturing and overall business ethos, with decisions made so that they have minimum negative impact on the environment.

Australian Forestry Standard

Our product is manufactured from managed and renewable plantation pine and is Australian Forestry Standard Chain of Custody certified.

PEFC

We manage waste responsibly through numerous recycling programs, including waste timber such as saw dust being recycled back into energy. We subscribe to local Government initiatives and voluntary audits, as well as our own internal environmental sustainable initiatives.

CLEANING AND CARE INSTRUCTIONS

Step 1. Wipe down using a damp soft cloth containing warm soapy water, followed by drying using a soft or microfibre cloth so as not to leave any residue on the door or panel. If this is sufficient there is no need for any further action.

Step 2. For more stubborn stains, use a good quality streak free glass cleaner as per the manufacturer's recommendation. You may also use Methylated Spirit on a soft cloth, using a circular cleaning motion being careful not to rub too hard.

Step 3. Repeat step 1 - Wipe down using a damp soft cloth containing warm soapy water, followed by drying using a soft or microfibre cloth so as not to leave any residue on the door or panel.